



## Instructions for iStar 30 watt Internal Ballast HID

**NOTICE: THIS LIGHT IS NOT SERVICABLE BY THE CUSTOMER. ANY EVIDENCE OF DISASSEMBLY VOIDS THE WARRANTY!**

Thanks for purchasing the latest technology in HID lighting! We strive to produce the best quality, best looking products while providing exceptional performance.

1. There are 2 wires coming out of the lights as follows:
  - a. White – Incoming power (+)
  - b. Black – Ground (-)DO NOT REVERSE POLARITY! DAMAGE TO ELECTRONICS WILL RESULT!
2. Voltage: 9-15 volts. The protective circuitry of the ballast will switch off the lamp outside these parameters.
3. A fuse of at least 10 but no more than 20 amps MUST be used.
4. Firmly mount using the 3/8" bolt provided. Attach the mounting bolt to the mounting point (tab/bracket/etc) FIRST then attach the light to mounting bolt. DO NOT USE THE LIGHT HOUSING TO TIGHEN THE LIGHT ON THE MOUNTING POINT!
5. Cold start.
  - a. The lamp will take approximately 10-15 seconds to reach full brightness and color.
  - b. If the lamp fails to light, switch off wait 1-3 seconds and switch back on.
  - c. Occasional spots of brown, yellow or pink within the beam is normal and should dissipate as the light comes to full operating temperature.
  - d. Slight flickering of the beam is normal and should dissipate as the light comes to full operating temperature.
6. Warm start.
  - a. The lamp may be switched on and off as needed with no waiting between cycles. However, the longer the lamp is allowed to run the longer it will last and the longer the color temperature will be maintained.
  - b. If the lamp fails to light, switch off wait 1-3 seconds and switch back on.

**HID Warranty supplement.** The regular Weekend Concepts warranty is in full effect EXCEPT for the following provisions:

1. Lamp – 90 Days from date of purchase. Warranty covers failure only; color temperature, spots, flickering and wire damage are not covered.
2. Ballast – 1 year from date of purchase. Warranty covers failure only; wire damage, over volt damage, and damage from crossed polarity are not covered.
3. If the light fails within the time frame of the warranty it MUST be serviced by Weekend Concepts. Removal of the light and sending it in for service is REQUIRED, NO EXCEPTIONS. Call Customer Service @ 805.226.8200 to obtain a return number for inspection. As stated above the light is not serviceable by the customer and any evidence of disassembly, damage or modification by the customer voids all warranties. Weekend Concepts will not modify the light in any way on behalf of a customer.
4. For full warranty information go to [lazerstar.net](http://lazerstar.net)